


Pipe Sizing Chart







Pipe size can be confusing. A one inch pipe is neither exactly 1'' on the inside or outside. A 1/4'' pipe is close to 1/2'' on the outside. We provide our customers with these charts to make it simple. To determine what pipe size you have on the outside use the chart on the left. Place the center of the pipe on the horizontal line and read the correct size.

NOTE: When printing this pg.
Turn off "scaling" in your printer dialog box to keep accuracy

For measuring the correct size of a female fitting, place the center of the pipe under the edge of the bottom of this page and measure across the center of the opening. For ease of measuring, fold page up so lines come to the page bot-

tom.

